

No.	Part n°	Description	Q'ty
1	CT100-01	Hex. Screw	1
2	CT100-02	Wheel Washer	1
3	CT100-03	Wheel	4
4	CT100-04	Wheel Cover	1
5	CT100-05	Cap Screw	1
6	CT100-06	Spindle	1
7	CT100-07	Housing Cap	1
8	CT100-08	Lock Ring	2
9	CT100-09	Ball Bearing (6000ZZ)	1
10	CT100-10	Front End Plate	1
11	CT100-11	Spring Pin (Φ2.5x4)	1
12	CT100-12	Spacer	1
13	CT100-13	Rotor	1
14	CT100-14	Rotor Blade	1
15	CT100-15	Cylinder	1
16	CT100-16	Rear End Plate	1
17	DG1002L-17	Spring Pin (Φ2.5x20)	1
18	DG1002L-18	Valve Screw	1

No.	Part n°	Description	Q'ty
19	DG1002L-19	O-Ring (ID9.8x2.4)	1
20	DG1002L-20	Valve Spring	1
21	DG1002L-21	Throttle Valve	4
22	DG1002L-22	O-Ring (P4)	1
23	DG1002L-23	Valve Shaft	1
24	DG1002L-24	Throttle Lever Assy	1
25	DG1002L-25	Spring Pin (M3x18)	1
27	CT100-27	Ball Bearing (696ZZ)	2
32	CT100-32	Spanner (14)	1
33	CT100-33	Spacer	1
36	CT100-36	Hatted Wrench Key (3/16")	1
41	DG1002L-41	Housing	1
42A	DG1002L-42A	Muffler	1
43	DG1002L-43	O-Ring (S022.4)	1
44	DG1002L-44	Exhaust Sleeve	1
45	DG1002L-45	Inlet Bushing	1
46	DG1002L-46	Housing Cover	1

